

## INSTALLATION INSTRUCTIONS

### PACKAGE CONTENTS

- Light board & Bulbs
- Control Unit
- Mounting Screws
- Lens
- Instructions
- Sensitivity Control Knob (Speaker Bar Only)
- **Colorbar Included with Speaker Bar Combo Only**
- **If anything is missing please notify the store you purchased it within 48 hours from the time of purchase.**

### Lens Installation

1. To install the lens remove (4) nuts from the rear of the speaker grill.
2. Lay grill down and line lens up in between the 4 prongs on the grill.
3. Leave the grill laying down & attach housing on top and put screws back in.



LENS GRILL



LENS HOUSING

### Sensitivity/Volume

For best results, turn your sensitivity knob about halfway with your music volume about the same, and the higher you turn the sensitivity the brighter the lights will be. If your music volume is high, lower your sensitivity to even the system out and vice versa. Every song will cause the lights to react differently. Choose your preference and enjoy the light show.

### Changing Bulbs

To remove bulbs use one hand to hold the wires and the other to gently pull the bulb out of the receptacle. To replace bulbs make sure both pins are lined up with the receptacle holes and gently push it in. Do not push the head of the bulb through the hole in the light board. Push the bulb in the board and attach/reattach from the back. If it does not go in smoothly, move it from side to side while pushing it into place. If Bulbs do not work make sure they are secured in the receptacle. Secondly, look to see if they have shorted out. (If wires inside the bulb are separated bulb is blown out)

### Caution and Warning

Do not mount the unit anywhere that may obstruct your view while driving. Always select your sensitivity before or after operating your vehicle.

**\*Only use Original bulbs purchased from the manufacturer or its distributors.  
Usage of other bulbs will void your warranty. To purchase bulbs, call (562)483-1445.  
90 Day Limited Warranty**